



How to Turn Off Your Printer's Firmware Update When Using Replacement Brother TN Series Toner Cartridges

**Universal for: TN-2510/2530/2560/2590/830/32J;
TN-3600/3602/3605/3607/3608/3609/920/70J**


Step 1: Click the tool icon.




Step 2: Click "All Settings".



Step 3: Scroll down and click "Machine Information".




Step 4: Scroll down and click "Firmware Auto Check".



Step 5: Click "Off".



Step 6: Finally, check to make sure the status of "Firmware Auto Check" is "Off".




If your printer is a non-touch-screen printer, please carry out the following steps on your computer.


Step 1: Click "Brother Utilities".




Step 2: Click "Tools".



Step 3: Click "Software Update Notification".



Step 4: Click "Turn off notification".



Step 5: Click "OK".

